


NOTES:

1. Secure the CB-18 anchor to a structural member capable of resisting a 5000 lb. load.
2. Use at least 6 of the $\frac{9}{16}$ " holes provided to attach the CB-18.
3. Use $\frac{1}{2}$ " diameter, Grade 5 All Thread or better.

INSTALLATION INSTRUCTIONS			TITLE CB SERIES ROOF ANCHOR			
DESIGNED BY:	B. WOODYARD	1992	DWG NO.		SIZE	REV
DRAWN BY:	PHIL GOMES	12/01/2005	CB-18 WELDMENT		A	NEW
CHECKED BY:	M. VOLLMER	12/01/2005	SCALE: NONE		SHEET: 1	
APPD BY:	M. VOLLMER	12/01/2005				