

# Reusable Stainless Anchor

<p><b>REUSABLE ANCHOR</b> Guardian Fall Protection 800-466-6385</p> <p><b>WARNING!</b> Failure to read and follow instructions included at time of shipment can result in serious personal injury!</p> <p>Fastener must use 1/4" x 2" fasteners provided. Replacement screws must be ordered for each installation.</p> <p>All fasteners must attach to solid. Use only with compatible equipment.</p> <p>5,000lb anchor, 60k capacity 1 piece at 310lbs.</p>	<p><b>REUSABLE ANCHOR</b> Guardian Fall Protection 800-466-6385</p> <p><b>WARNING!</b> Failure to read and follow instructions included at time of shipment can result in serious personal injury!</p> <p>Fastener must use 1/4" x 2" fasteners provided. Replacement screws must be ordered for each installation.</p> <p>All fasteners must attach to solid. Use only with compatible equipment.</p> <p>5,000lb anchor, 60k capacity 1 piece at 310lbs.</p>
---	---



## WARNING! PLEASE READ CAREFULLY BEFORE USING

- Do not alter or misuse the equipment
- Do not use combinations of components or subsystems which may affect or interfere with the safe function of each other
- Do not expose the equipment to chemicals that may produce a harmful effect. Consult Guardian in cases of doubt.
- Do not use the equipment around moving machinery and electrical hazards.

- **BEFORE USING REFER TO ANSI Z359.1 AND APPLICABLE REGULATIONS GOVERNING OCCUPATIONAL SAFETY. FOR PERSONAL FALL PROTECTION ONLY! READ THIS LITERATURE CAREFULLY BEFORE USING THE EQUIPMENT.**
- A copy of manufacturer's instructions shall be provided to users before equipment use begins. Failure to follow the instructions included with this product can result in serious injury or death.
- Users are required to have a rescue plan and the means at hand to implement it when using this equipment.
- **DO NOT HANG EQUIPMENT, RIGGING, OR STAGING FROM FALL PROTECTION ANCHORS.**

# GUARDIAN

## FALL PROTECTION

26609 79<sup>th</sup> Ave. S. Kent, WA 98002  
Phone: 800-466-6385 [www.guardianfall.com](http://www.guardianfall.com)

## REUSABLE ANCHOR MODELS AND DESIGNATIONS

<i>Part Numbers</i>	<i>Description</i>
00470	Reusable Anchor for any pitch
00475	Fastener Replacement Kit

## **READ INSTALLATION INSTRUCTIONS BEFORE USING!**

Reusable Anchors must be installed with all fasteners penetrating a structural roof truss. Anchors can be mounted directly into the truss or through the roof sheathing. User must ensure that they use the equipment in a compliant manner, and that they are not situated to have a free fall greater than 6ft.

**One worker per anchor. Maximum capacity is 310 lbs.**

## **INSTRUCTIONS FOR INSTALLATION!**

### **Warnings:**

All fasteners must penetrate a structural truss capable of withstanding 5,000lb loads in the direction that a fall might occur.

Compatible components must be used. Do not attach subsystems or lifelines in a manner that does not meet OSHA compatibility standards.

### **ANCHOR POINT PLACEMENT:**

Do not place anchors within 10ft. of the gable ends of the roof. Recommended spacing to ensure availability of anchors at all times is 16ft. o.c. along a ridge-line or in the field. Use the anchor point that creates the least swing fall potential. Free fall cannot exceed 6ft.

### **INSTALLATION INTO TRUSS:**

Bend the anchor legs at their creases to match the roof pitch. All 10 of the included #12x2" screw fasteners must fully penetrate the structural truss. If a fastener cannot penetrate the truss reinstall the anchor at a different location where all fasteners can penetrate the truss. A drill must be used to install the fasteners. DO NOT HAMMER screws. Do not use nails!

### **REMOVAL AND REUSE:**

Anchors can be reused provided that they sustain no damage and have not been subjected to a fall arrest. Do not reuse original fasteners after removal. Discard them. New Guardian fasteners must be used at each installation.

## **INSPECT EQUIPMENT BEFORE EACH USE!**

### **Reusable Anchor inspection instructions:**

Reusable Anchors should be inspected at least annually as a part of a regular safety program. Daily inspections should at the least include a check to see that all of the components of the equipment are performing properly. Common sense dictates procedures for visual inspections.

- When inspecting equipment, check for physical deformations, excessive wear, corrosion, and that all components work properly and safely.
- Inspect connecting hardware and webbing of any other system components daily.
- If product fails inspection contact your local dealer or Guardian for replacement information.

## **MAINTENANCE, CLEANING, AND STORAGE**

Only a qualified person trained by Guardian to service or replace the equipment can carry out servicing the equipment. All services and inspection dates should be logged and maintained by the company safety officer.

**Remove from service all products subjected to fall arresting forces.** Guardian will replace any of its components involved in a fall arrest. Contact Guardian for policy specifics.

**Cleaning after use** is important for maintaining the safety and life of the equipment. Cleanse the equipment of all dirt, corrosives, and contaminants. If equipment cannot simply be wiped clean use a mild commercial soap and water. Wipe and hang to dry.

**Store equipment** where it cannot be affected by heat, light, excessive moisture, oil, chemicals, or other degrading elements.